

BARKER & WILLIAMSON
603 CIDCO ROAD
COCOA, FL 32926
321-639-1510
www.bwantennas.com

BROADBAND FREQ AGILE HF FOLDED DIPOLE ANTENNA
CAMOUFLAGED FOR FORWARD TACTICAL USE

Model	Length	SWR <2:1	SWR <3:1	Spreaders	Wire Material
BWDI-20N	20 Ft	14 - 30 Mhz	30 - 60 Mhz	Fiberglass	Insulated Copper
BWDI-45N	45 Ft	7 - 30 Mhz	30 - 60 Mhz	Fiberglass	Insulated Copper
BWDI-65N	65 Ft	4 - 30 Mhz	30 - 60 Mhz	Fiberglass	Insulated Copper
BWDI-90N	90 Ft	1.8 - 30 Mhz	30 - 60 Mhz	Fiberglass	Insulated Copper
BWDI-180N	180 Ft	1.8 - 30 Mhz	30 - 60 Mhz	Fiberglass	Insulated Copper

Specify -S for sand camouflage, and -G for green camouflage.

The Barker & Williamson Broadband Folded Dipole Antenna is designed for continuous frequency operation over its specified range. The antenna comes fully assembled and pretuned so no measuring or cutting is required. It is all weather rated at 2KW PEP Input, 1 KW PEP Output SSB/CW ICAS (Intermittent Commercial and Amateur Service), and permits use of the full capabilities of today's continuous coverage transceivers. Its single feedline operation for all bands provides excellent performance for military, emergency management, commercial, and amateur installations. Instant tuning with no moving parts allows continuous ALE operation. Installation will determine the type of propagation, with skywave/groundwave combination, or just skywave for NVIS use. 1KW PEP Output power CCS (Continuous Commercial Service) requires the HFT-1 balun and LD-9 matching unit.

These antennas are fully camouflaged. Features include a high impact plastic housing for the balun. The matching unit and wire spreaders are FRP fiberglass. Feedline impedance is 50 ohms, and the antenna is equipped with a female N connector. The wire is PVC insulated copper with a rope lay. For the best mid/long range omni-directional radiation, installation as a shallow inverted Vee is suggested. For NVIS install as a flat-top low to the ground. These antennas require a three pole installation, using our FDMK or MK114-CM center mounting kit. We offer complete rapid deployment kits, with fiberglass poles and carrying bags. We also offer the BAG-FD-D camouflage antenna carry bag with weather resistant take up spools.

WARNING: Do not install where antenna conductors could come in contact with your utility wires. Do not install over or under utility wires, as wire breakage could cause contact to occur. People and pets must not come in contact with antenna conductors during transmit operation. Refer to FCC rules on determining a safe zone around the antenna. Balun and balancing network may become hot during high power operation.

Planning: Determining How and Where to Install

Remember that any radio station is only as good as its antenna. Take the proper time and care to plan it out. A successful installation requires attention to antenna height, surrounding objects, feedline choice, location and orientation.

(1) NVIS propagation is performed as a flat-top with height varying from ground level to approximately 12 feet. This height is dependent on the ground (soil) conditions. It may be possible to lay the antenna on the ground in desert/low water table environments. The B&W NVIS mast kits allow multiple heights. In NVIS installations a counterpoise will sometimes enhance performance. If you are not getting enough distance from your NVIS setup, try raising the center of the antenna a few feet to make a very shallow inverted Vee. (Appropriate NVIS daytime frequencies are approx 5-12 Mhz, nighttime are 2-4 Mhz.)

(2) Conventional propagation minimum clear height is recommended at 25 feet for operation down to approx 3.5 Mhz (ends 12 feet for inverted Vee or sloper), and 40 feet for 1.8 Mhz (ends 20 feet for inverted Vee or sloper). Less height does not disqualify operation, but may require a tuner on the lowest frequencies. Also, propagation may be reduced with inadequate height on the lower frequencies.

(3) This is a non-grounded antenna, so surrounding "grounded objects" try to absorb your radiated wave on low frequencies. This may result in poor SWR, and/or poor signal reports. "Grounded objects" include metal towers/poles, roofs, gutters, trees, and the ground itself. When supporting from metal towers/poles, step off (or up) from the metal with a wood or PVC support arm 3 to 5 feet. Avoid crossing over roofs when possible. When using trees for supports, try to stay clear of the branches.

(4) When installing in an attic or close to a roof, remember that gutters, power line, and conduit/pipe runs become antennas that may cause coupling problems at certain frequencies. Attempt to stay perpendicular to such objects. Always keep the balun and balancing network hanging in the air with proper support such as an FDMK, away from wood and insulation to avoid fire hazard.


(5) Use the proper feedline. Examples are RG-8 (thick), RG-213, 9913. Over 50% of installation problems are coax/connector problems. Check your feedline (including new ones) with a dummy load placed at the antenna end of the coax. Transmit into the dummy load and check for 1:1 SWR on all bands. Do not substitute an analyzer for this step. Thin coax such as RG-8X may be used up to 20 watts.

(6) The location will usually be determined by trade-offs of height, available supports, and interfering objects. Sometimes, multiple trials may be necessary to judge which installation is best. Unfortunately, HF is difficult to predict. Usually, adequate height is favored over other parameters.

(7) Remember that the highest amount of energy is radiated at a right angle to the antenna wire, the minimum off the ends (when the antenna is parallel to the ground). Consider this when selecting map orientation for your antenna. By using an inverted Vee, you may change the angle of radiation, and therefore affect the distance of transmission at different frequencies. Put simply, the steeper (more vertical than horizontal) an inverted Vee is made, the more it will favor DX, and tend to skip over local stations at low frequencies. We recommend roughly 30 degrees angle down on a leg from horizontal for best general, overall results.


INSTALLATION INSTRUCTIONS

- (1) Determine your supports, paying attention to best possible height, antenna configuration, and alignment. Trees, sides of a building, utility poles, etc. make good supports. Do not install parallel to power lines if it can be avoided.
- (2) Unpack the antenna. Lay it on the ground, the two rolls separated and the components laying in the middle.
- (3) Cut enough polyester rope (3/16" diameter) and prepare ends as shown in Figure # 1.
- (4) Uncoil one half of the antenna. Avoid twisting or kinking by keeping a little tension during unrolling. Let the shipping tube rotate in your hands - do not pull the wire off the ends as it will kink.
- (5) Install the rope as shown in Figure # 1. If you keep the top arm of the rope 1" - 3" shorter than the bottom arm, the antenna will hang in a proper vertical position instead of rotating flat.
- (6) Repeat steps # 4 and # 5 to the other side of the antenna.
- (7) Attach your coax cable and raise the antenna up in the air. Again avoid twisting or kinking.
- (8) Run the coax to the station. Run the coax down to the ground, and then perpendicular to the antenna for as far as possible. If this is not done properly, you will transmit onto the shield of the coax, causing high SWR and transmitter power cutback. Only use a sufficient length of coax to reach the station
- (9) Your antenna is ready for operation. It is broadband and pretuned at the factory for an average SWR of 1.4:1 to 2.0:1 in HF depending upon the frequency used and surrounding objects, ground conditions, etc. You may find that in extremely bad locations the use of an antenna tuner will be helpful. SWR of 2:1 to 3:1 should be expected on 6 meters without a tuner.




TYPICAL INSTALLATIONS

BALUN AND TERMINATOR
MAY BE SUPPORTED WITH
FDMK MOUNTING KIT



THREE POLE INSTALLATION

"FLAT TOP" AS SHOWN IN SOLID LINES
INVERTED "V" AS SHOWN IN BROKEN LINES



WARRANTY STATEMENT

Barker & Williamson guarantees each product to be free from defects in material and workmanship for 90 days from date of purchase. The warranty applies to the original purchaser only, and we will repair or replace the product at our discretion. Under no circumstances will Barker & Williamson be liable for any damages or consequential damages arising from use or misuse of our products. Warranty is voided if product is subject to misuse, neglect, accident, improperly installed or used in violation of the instructions furnished by us. We reserve the right to make changes in design at any time without obligation to update previously manufactured models. This warranty is given in lieu of any other warranty, expressed or implied.