


**Figure 1**

### ASSEMBLY

Referring to figure 1, first attach the short plastic cross arm to the bottom of the long plastic vertical support with two #8 flat head self tapping screws. They will cut their own threads into the cross arm. It is normal for a little plastic to crack out of the top of the hole when starting the thread. Next, attach the stainless steel clamp to the top of the vertical support using the 1/4-20 flat head machine screw, flat washer, and self locking nut.

Now you may begin attachment of the antenna. Attach the balancing network in the metal clamp, using the long 1/4-20 machine screw and a self locking nut. Remember to keep orientation so that the drain hole will be down. Clamp the balun to the short plastic cross arm as shown in figure 2 using the plastic strap with the remaining 1/4-20 machine screws, flat washers on both sides, and self locking nuts.



**Figure 2**